

NOTICE D'INSTALLATION

STATION DE GONFLAGE ALTAO® PUMP



PRECAUTIONS

Pour la fixation au sol de la station de gonflage ALTAO® PUMP, nous vous fournissons trois tirefonds Ø M8 avec rondelles plates et des chevilles plastiques.

Attention : Ce mode de fixation ne convient que sur des sols de type béton.
Si le sol est d'une autre nature, utilisez des éléments de fixation adaptés
Prévoir scellement chimique non fourni pour pose sur enrobé



Pour un confort d'utilisation, nous vous conseillons, de placer la station de gonflage ALTAO® PUMP à une distance d'un mur ou de tout autre obstacle de :

- Côté flanc fixe : 50 cm mini
- Côté flanc amovible : 1m si vous avez opté pour une station standard, 2.5m si vous avez choisi l'option fente latérale pour le maintien du vélo
- Arrière de la station : 18 cm mini

NB : Voir plan fourni

MATERIEL NECESSAIRE

- 1 perforateur
- 1 forêt Ø 12
- 1 clé à pipe n°13
- 1 mètre
- 1 marqueur

INSTALLATION

1. Placez la station de gonflage ALTAO® PUMP à l'endroit souhaité.
2. Marquez la position des 3 trous Ø15 mm percés dans le socle de la station.
3. Retirez la station de gonflage et percez le sol au niveau des marques à l'aide de votre perforateur équipé d'un foret Ø12mm. Les trous doivent avoir une profondeur de 80mm au minimum.
4. Placez à l'intérieur de ces trous les chevilles en plastiques.
5. Remplacez la station de gonflage et vissez les tirefonds + rondelles avec la clé à pipe n°13.

ATTENTION : Le flexible de gonflage doit impérativement être brancher avant d'utiliser la station.

Votre station de gonflage ALTAO® PUMP est maintenant installée. Vous pouvez la mettre à dispositionPeux-tu on des cyclistes !

INSTALLATION INSTRUCTIONS

AIR INFLATING STATION ALTAO® PUMP



PRECAUTIONS

To fix ALTAO® Pump in the floor, we supply 3 long screws Ø M8 with flat washers and plastic rawplugs.

Caution : This way of fixing is convenient only for floors like asphalt or concrete.
If the floor is different, use fixing elements adapted.



To use it easily, we suggest you to install the station spaced from a wall or any other obstacle:

- On the fixed side: mini 50cm
- On the removable side: 1m if you chose the station without lateral slot; 2.5m if you chose this option (to put your bike).
- Back of the station: mini 18cm

MATERIALNEEDED


- 1 hole puncher
- 1 drill-bit Ø 12
- 1 socket wrench n°13
- 1 measuring tape
- 1 felt-tip marker

INSTALLATION


1. Place the station ALTAO® Pump where you want to install it.
2. Mark the position of the 3 holes Ø15 mm drilled on the station base.
3. Remove ALTAO® Pump station and drill the floor on the 3 marks thanks to a hole puncher and a drill-bit Ø12mm. Holes depth must reach 80mm minimum.
4. Install inside these holes plastic rawplugs.
5. Put back the station and screw long screws and washers with socket wrench n°13.

Your inflating station ALTAO® Pump is now installed. You can make it available to bikers !

PLAN DU PLOT BETON
CONCRETE BASE DRAWING






COUPE A-A
Section A-A



FACE AVANT PUMP
ACCES PEDALE DE POMPAGE
*Front face of Pump
Access to the pumping pedal*

PLAN DE POSITIONNEMENT DE LA PUMP (ECH : 1/20)
PUMP POSITION DRAWING (SCALE: 1/20)



ALTINNOVA

INSTALLATION SUR SOL MEUBLE _ DALLE BETON NECESSAIRE

ALTAO® PUMP

INSTALLATION ON UNSTABLE GROUND _ CONCRETE BASE NEEDED

DO NOT SCALE DRAWING

1 2 3 4 5 6 7 8

A

B

C

D

E

F

1 2 3 4 5 6 7

PLAN DE POSITIONNEMENT DE ALTAO® PUMP
ALTAO® PUMP POSITION DRAWING

MUR - Wall

180

MUR - Wall

200

1800

ESPACE D'IMPLANTATION UTILE
Necessary area

DISTANCES MINIMALES A RESPECTER
POUR L'IMPLANTATION DU PRODUIT
Minimum distances to install the product

2485

MUR - Wall

MUR - Wall

DO NOT SCALE DRAWING

A3

FEUILLE:
2/4

ECH:
1:15


ALTINNOVA
ALTAO® PUMP

INSTALLATION SUR SOL DUR _ DALLE BETON INUTILE
INSTALLATION ON HARD GROUND _ NO CONCRETE BASE NEEDED

The drawing consists of two main parts: a top-down plan view and a 3D perspective view. The plan view shows a rectangular area of 2485mm by 1800mm, labeled 'ESPACE D'IMPLANTATION UTILE' (Necessary area). The pump unit is shown in the top right corner, with a 200mm clearance from the right wall and a 180mm clearance from the top wall. The 3D view shows the pump unit and a bicycle for scale, with labels 'MUR - Wall' indicating the required clearances.

ALTAO® PUMP

INSTALLATION ON HARD GROUND _ NO CONCRETE BASE NEEDED



LE DIAMETRE DE PERCAGE AU SOL EST EN RELATION AVEC LE TYPE DE FIXATION UTILISE
SE REFERER A LA NOTICE D'INSTALLATION

Diametrer of drilling depends on the fixings used
See user instructions

A
B
C
D
E
F

COTE FLANC AMOVIBLE
Side of removable panel

COTE FLAN FIXE
Side of fixed panel

A3		FEUILLE:	3/4	ECH:	1:1
GABARIT PERCAGE ANCRAGE AU SOL		ALTINNOVA			
Drilling pattern to fix ALTAO Pump on the floor		ALTAO PUMP			

